



Thank you for the purchase of your New Green Machine LSV Cart. You should expect years and years of reliable use from it. There are several important things that you will need to do to help make this happen.

Break In:

### **GAS UNITS**

The break-in period is a very important time with any new vehicle. The typical break-in period happens within the first 350 miles. During this time your vehicle will get smoother, increase power, allow for smoother turning and get quieter.

Here are a few of the items that you will need to do to help extend the life of this vehicle.

- The manufacturer has lubricated the engine with a special blend of oil to help with this process, with this blend it will dissipate quickly. During this period **YOU WILL NEED TO CHECK AND ADD OIL AT 50 miles**, again at every 50 mile intervals until fully broken in. May only take a small amount (1/4 to 1/2 qt) each time but it is essential that you keep it full. **DO NOT OVERFILL**. Please see owners manual for details on checking and adding oil. *15W-40 is recommended but 10w-40 can also be used.*
- The manufacturer has also added a special blend of break-in fuel to to fuel system. This is a strong oil based fuel, with that said you need to add Premium fuel for first fill up. It may take the first full tank run through the system to fully flush out the factory blended fuel. C During this time the vehicle can be harder to start and limit the performance. Please be patient as this will clean out during the first tank use.
- During the break-in period it is very IMPORTANT TO NOT RUN VEHICLE AT HIGH RPM'S (ABOVE 6000) FOR AN EXTENDED TIME. Do not run Vehicle at full throttle for longer than 30 seconds at a time. **IF EVER CART STALLS AND SMELLS OF GAS, THIS IS TYPICALLY CAUSED BY RUNNING ENGINE AT TO HIGH OF AN RPM FOR LONG PERIOD OF TIME AND OVERHEATING ENGINE. THIS WILL CAUSE CHOKE TO ENGAGE AND FLOOD ENGINE. LET ENGINE COOL DOWN AND DO NOT DRIVE IT THAT HARD AGAIN . ESPECIALLY DURING BREAK IN PERIOD.**
- Check lug nuts at every 50 miles of use for the safety of all passengers.
- Must start and run the Motor for at least 10 minutes every month, this will help keep the fuel system clean and reduce the chances of build up of tarnish in the carburetor.
- You may also notice during this time some bolts or nuts may loosen up as the vehicle settles with use. Please tighten anything to spec per manual if needed.

It is recommended that you add a fuel treatment to fuel before any long term storage. Run motor for at least 10 miles with treatment before storage for longer than 1 month.

### **ELECTRIC UNITS**

- You may also notice during this time some bolts or nuts may loosen up as the vehicle settles with use. Please tighten anything to spec per manual if needed.
- You must charge the batteries at least once every 2 months. This means you must unplug unit for 1 minutes then reinsert plug in unit. Failure to do so can cause premature failure or shorten the life of the batteries.

### **ALL UNITS**

After break in period you should still follow the break in suggestions during normal use and follow the manufacturers owners manual directions.

MUST GO TO [WWW.GREENMACHINECARTS.COM/WARRANTY-REGISTRATION](http://WWW.GREENMACHINECARTS.COM/WARRANTY-REGISTRATION) TO REGISTER FOR WARRANTY WITHIN 15 DAYS OF PURCHASE TO REGISTER WARRANTY. FAILURE TO DO SO WILL RESULT IN LOSS OF WARRANTY COVERAGE.

Please check with our website for valuable videos on some key features of this unit.